



Quick Start Guide: X-keys Trigger Switch for XNote Stopwatch


Plug the X-keys Trigger switch in an available USB port and wait for Windows to recognize it. Open Xnote Stopwatch and select Hotkeys from the More menu.



Click in the field for each control you want to program and press the button on the trigger switch. The macro pre-programmed in the trigger switch will appear.



After you have assigned all three buttons, the screen should look something like this. Click OK to save the hotkey assignments.



For more information on setting up and using XNote Stopwatch, please refer to <http://www.xnotestopwatch.com/help/>